Estate®

CONTROL PANEL PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)

MICROWAVE
HOOD
COMBINATION



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8184642	Guide, U & C
	LIT8183991	Instructions, Installation
	LIT8184643	Tech Sheet
	LIT8184644	Guide, Cooking

Illus. No.	Part No.	DESCRIPTION
2		Control Panel
	8184330	Black
	8184334	White
	8184942	Biscuit
3	8184643	Bracket, Control
4		Key Membrane
	8184939	Black
	8184940	White
	8184941	Biscuit

Illus. No.	Part No.	DESCRIPTION
5	8184654	Microcomputer
9		Screw
	4358762	Black
	4358381	White
10	4358883	Screw
11	4358489	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



Illus. No.	Part No.	DESCRIPTION
1		Door Assembly
	8184328	Black
	8184332	White
	8184946	Biscuit
2	8172111	Frame, Door
3	8171844	Tape, Seal
4	8171850	Latch
5	8184016	Spring, Latch
6		Panel, Door
	8184329	Black
	8184333	White
	8184948	Biscuit
7	8184746	Glass, Door
8		Handle, Door
	8184389	Black
	8184390	White
	8184947	Biscuit
9	8171846	Choke, Cover
11		Screw
	4358381	Black
	4359009	White

CABINET PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



Illus. No.	Part No.	DESCRIPTION
1		Outer Case
	8184034	Black
	8184035	White
	8184760	Biscuit
2	4358928	Mounting Bracket
3		Cavity Assy
		Not Serviceable
4		Grille Vent
	8184943	Black
	8184335	White
	8184944	Biscuit
9	8184655	Plate, Mount
12	4358381	Screw
13		Screw
	4358762	Black
	4359009	White

MAGNETRON AND AIR FLOW PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



Illus. No.	Part No.	DESCRIPTION
1	4359731	Magnetron
2	8184046	H.V. Transformer
3	4359497	Bracket, H.V.
4	8183536	Capacitor, H.V.
6	4359155	Motor, Turntable
7	8184043	Plate
9	4359502	H.V. Diode Cable
11	8184044	Plate
12	8184748	Shield, Protector
14	8184033	Canopy
16	4358192	Screw
17	4359509	Rotating Ring
18	8171863	Turntable Shaft
19	8184036	Glass Tray
21	4358489	Screw
23	4358188	Screw

INTERIOR PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)

Illus. No.	Part No.	DESCRIPTION
2	8184045	Air Duct
7	8184049	Thermostat
9	4359964	Cover
10	4359518	Lamp, Holder
11	4158344	Oven, Lamp
12	8184041	Motor, Ventilation
13	8184048	Lead, Wire
14	8183507	Fuse
15	4358659	Fuse Cap
16	8184047	Power Cord
20	8183916	Charcoal Filter
21	4358381	Screw
24	4358489	Screw

MISCELLANEOUS PARTS

Illus. No.	Part No.	DESCRIPTION
		Following Parts Not Illustrated
		SEALER
	482338	Sealer, Silastic (3 Oz.)
	4358404	Installation Hardware

LATCH BOARD PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



Illus. No.	Part No.	DESCRIPTION
1	8183558	Board, Latch
2	4158940	Micro Switch
3	4158941	Micro Switch
4	4358795	Lever Monitor
5	4358051	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

VENTILATION PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



Illus. No.	Part No.	DESCRIPTION
1	8184051	Base Plate Assy
2	4359527	Bracket
3	4359528	Glass, Cooktop Lamp
4	8184042	Lead Wire Assy
6	4358971	Oven Lamp
7	4359518	Lamp Holder
8	4358853	Air Filter
9	4358380	Screw

INSTALLATION PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INSTALLATION PARTS

For Model: TMH14XLB0, TMH14XLQ0, TMH14XLT0
(BLACK) (WHITE) (BISCUIT)

Illus. No.	Part No.	DESCRIPTION
1	4158541	Exhaust Adapter
2	4158319	Exhaust Damper
3	4158321	Toggle Bolt/Wings
4	4158326	Toggle Wing
5	4158323	Screw
6	4158315	Screw
7	4158314	Washer
8	8184050	Plate, Mounting Wing
9	4358011	Clamp
10	4358012	Bushing
11	8183896	Sheet−Top Cabinet Template
12	4359011	Sheet−Wall Template
13	4358381	Screw
15	4358010	Screw
16	4358933	Pin, Locking